



She's one of a kind

Give her the unique protection of the Hugs® system

Reliable and secure infant protection

Protecting over 1 million babies every year

The Hugs system delivers an unmatched level of security against infant abduction and mother/infant mismatches. Trusted by hundreds of hospitals worldwide, the Hugs system offers the reliability that you and your staff can depend on every day to keep your infants safe.

It's a choice leading hospitals have made. And a choice parents, nurses, administrators and security staff alike can wholly support.

The Hugs System Advantage

Easy-attach tag with automatic enrolment

The Hugs tag attaches in seconds and is automatically enrolled in the software. Protection can start right in the delivery room.

No manual tests

The Hugs system requires no manual testing of infant tags or other devices to make sure they're working. The Hugs software continually monitors the status of all devices, and will generate an alarm if something goes wrong.

Automatic mother/infant matching

With the Kisses® option, the Hugs system automatically alerts you if the wrong baby is brought to the wrong mother. There are no numbers to match and no wall-mounted lamps to check.

Support now, and in the future

The By Your Side™ customer support program ensures that every customer will be successful with infant protection. Stanley Healthcare Solutions is with you every step of the way as you implement and use your system, with a wide range of materials and services.

Clinically focused, task oriented

The Hugs software is organized around the focus of your care—your patients. To complete a task, just select the patient, select a task icon, and then follow the on-screen instructions.

Full supervision

The Hugs system ensures full supervision of all components, including the tag, with each tag sending a Heartbeat® status message every 10 seconds. If the system doesn't receive these messages for a specified time period, an alarm is automatically generated.

Simple and reliable

Each baby is fully protected the instant a tamper-proof Hugs tag is attached. The Hugs system offers full supervision, with all active Hugs tags reporting every 10 seconds to show they are present and functioning.

Here's how the Hugs system works. Every infant in your unit wears a Hugs tag with a unique ID number on the ankle, and every exit point is electronically monitored to detect the tags. This means staff and family can move infants freely within the protected zone, but no one can remove an infant from the unit without your staff being alerted.

Beyond this superior and active supervision of infants, the Hugs system monitors its own functionality and alerts staff of any problems.

Easy to use

As soon as a tag is attached to an infant, it is automatically activated and enrolled in the software. The system software gives you the essential information you need to do your job, with a large census view of all infants in the system.

Attaching the tag takes only a few moments, and enrolment in the software happens automatically. The BabySense™ feature also notifies you if the tag is not securely on the infant. You are given timely notice to snug up the tag.

Other procedures, such as moving the infant for tests, involve no more than a password and a click or two of the mouse. Keypads or access card readers can be installed at each exit to allow authorized staff to sign out infants at an exit.

This flexibility and the system's scalability allow you to adapt the system to your facility and to your existing clinical procedures—not the other way around. Your Hugs system is also fully supported by Stanley Healthcare Solutions and its network of authorized dealers.



Support for staff and patients

Effective infant protection requires successful integration into the clinical environment, and the participation of nurses, security staff and parents. Stanley Healthcare works with you to make implementation smooth and trouble-free.

Every Hugs system is backed by the By Your Side program, providing you with an unmatched level of support at every stage, from initial purchase to implementation to ongoing use.

Our "Implementation Guide for Nurse Managers" covers the essential points to ensure smooth deployment of an infant protection system within the clinical environment. We also offer a sample policy to help you devise your own procedures for using the system.

Stanley Healthcare Solutions can also provide on-site training and go-live support to help you through your first day of using the system. This is supported by a range of training tools. Senior staff members involved with the system are also invited to attend the Patient Security User Conference, which covers a range of topics on patient security, including best practises for using the Hugs system.

For parents, the "Helping to Protect Your Baby" pamphlet explains in straightforward language the infant abduction phenomenon, what to expect while in hospital, and how parents can play an active part in the security of their infant.

The Hugs system will alert your staff if:

- Someone tries to exit via a monitored door or elevator with a protected infant, without authorization.
- The strap has been cut or tampered with.
- The tag's signal has not been detected by the system for a specified time period.
- The tag's battery power is low.
- An authorized exit has occurred but someone tries to "piggyback" through the protected exit with another infant.
- An authorized exit has occurred but the infant has not been returned to the designated safe area in the specified time.

Effective security

In the event of an alarm, the Hugs system can automatically activate magnetic door locks or hold an elevator. It can also integrate with and activate other security and access control systems, such as alpha-numeric pagers and cameras.

For security purposes, all system transactions are password controlled, time and date stamped and logged into the database on the PC that controls the system. You'll have a permanent record of who admitted, signed out and discharged all babies. You'll also have a record of when and where alarms occurred and who cleared them.

The system can even display images from your CCTV system right within the Hugs software when an alarm occurs, so that staff can actually see what happened in the moments before the alarm.

Finally, the Hugs system can share devices with Stanley Healthcare's Pedz™ pediatric protection system and Passport™ patient protection system. Your Hugs system can form the cornerstone of a hospital-wide solution for patient protection in multiple departments.





Add Kisses mother/infant matching for total infant protection

Just bring mother and baby together and the optional Kisses component will alert you to a wrong match. By adding the Kisses option to your Hugs system, you have an easy, effective and electronic enhancement to manual band-matching systems.

Here's how it works. Each mother wears a small, comfortable Kisses tag. It is bonded with her infant's Hugs tag at birth and for the duration of their hospital stay. Every time the two are brought together, an audible signal from the infant's tag immediately alerts you of a mismatch—even if there are other infants in the room. There's nothing to visually check or match, just the clear sound of the Kisses component to ensure that you always deliver the right baby to the right mother.

Kisses mother/infant matching:

- Automatically and instantly alerts you to an incorrect match.
- Works anywhere in the area protected by the Hugs system.
- Patient-friendly mother tag attaches with standard hospital band.
- Allows you to use and reuse any Hugs tag with any Kisses tag for easier tag management.
- Supports multiple births.
- No extra administrative burden—no numbers to match, and no wall-mounted lights to check.

Call 1.866.559.6275 for more information.



Healthcare Solutions

About us

Stanley Healthcare Solutions is a leading provider of safety, security, and supply chain management solutions for healthcare. Every day, thousands of hospitals and senior care facilities worldwide rely on Stanley products to deliver better care and improve efficiency.

Our smart storage solutions include supply/procedure carts, cabinets and casework, small carts, open storage, heavy-duty storage, and inventory management systems.

In the senior care market, Stanley Healthcare offers a full range of resident safety and security applications,

including wander management, fall management and emergency call.

Our suite of patient security products provides individual protection to patients in multiple departments, from newborns in obstetrics to adults in the emergency department.

Stanley Healthcare Solutions will continue to expand its range of healthcare products and solutions for institutions and individuals, building on our years of experience in healthcare, and the Stanley legacy of quality and innovation.

For further information on the Hugs system:

Address: 309 Legget Drive
Ottawa, ON K2K 3A3
Canada

Toll free: 1.866.559.6275

Telephone: 1.613.592.6997

Facsimile: 1.613.592.4296

Web site: www.stanleyhealthcare.com

For proven protection, become a Hugs Hospital today. Stanley Healthcare Solutions is ready to help you find the right solution for your infant protection needs.